


Overview and Quick Start

Introduction to phone exterior



⚠️ Note:

There may be some differences depending on your phone model. The images used in these instructions are for reference only. Please refer to the actual product in use.

Introduction to buttons and widgets

1. **②Light & proximity sensors:** Automatically detects the intensity of the ambient light and adjusts the brightness of the screen accordingly.

When making phone calls, this sensor automatically detects the distance between you and your phone. If you are too close to your phone, it will switch off your screen to avoid unintentional triggering of certain functions. The sensor is inactive in headset and hands-free mode.

2. **⑤Volume button:** You can adjust the volume using the volume buttons.

3. **④Front camera/⑨Triple rear cameras:** You can take photos and record videos.

4. **①Receiver&Speaker:** You can hear the caller through the receiver when on the phone. Used to play sound.

5. **⑥Power button:** When the phone is powered off, long press the Power button to turn it on. When the phone is powered on, long press the button to turn off or reboot the phone.

Note:

When the phone cannot be used normally, simultaneously long press the **Power button** and the **Volume button**- for at least 10 seconds to force the device to restart.

6. **⑮Card tray:** Insert/Remove cards.

7. **⑯Pin port:** Insert the ejector tool into the hole and press it until the card tray ejects, then remove the card tray.

8. **⑭Main microphone/③Secondary microphone:** Used to transfer sound during calls.

9. **⑪Rear flash:** A light source.

10. **⑬Speaker:** Used to play sound.

11. **⑫USB port:** You can connect your phone to other devices such as a charger or computer using a data cable.

12. **⑦Ultrasonic fingerprint sensor:** The button has a fingerprint recognition function, which can be used to unlock the phone instead of a password.

13. **⑧Infrared remote control:** An infrared encoding signal can be sent to control home devices.

14. **⑩Laser autofocus:** Assists in camera focusing.

Installation and Preparation


Procedure for installing SIM card

 **Note:** You may have a single or dual SIM phone based on the needs of your region or carrier, but the differences between the two versions are not fully covered in the instructions. The pictures used in these instructions are for reference only and may differ from your phone.


This phone supports hot swapping of nano SIM cards (SIM1/SIM2). When the phone is on, it can automatically recognise inserted nano SIM cards (SIM1/SIM2).

This phone supports nano SIM cards (SIM1/SIM2).


1. Insert the ejector tool into the hole and press it until the card tray ejects, then remove the card tray.



2. Follow the arrow direction shown in the diagram and fit the angled corner of your SIM card into the angled corner of the tray.



3. With the touch screen facing up, insert the card tray according to the direction of the arrow (with a nano SIM card inserted).



Note:

1. The back cover cannot be removed, so as to prevent damage to the phone.
2. Place the SIM card on the card tray, then insert the card tray into the phone. SIM cards must not be inserted directly into the phone.
3. You are suggested not to cut your SIM card by yourself. If the nano SIM card (SIM1/SIM2) does not fit, please contact your carrier to change to a standard nano card.
4. This phone supports "Dual SIM Dual Standby Single Pass", which means that voice or data services cannot be used on both cards at the same time. When a call is established on one SIM card, the other one cannot make or receive calls. Callers to the other card may hear the message "The number you have dialled is not in service" or "The number you have dialled is temporarily unavailable. Try again later". When one SIM card is using a data connection, the other one cannot use data services. The above situation is due to the Dual SIM Dual Standby Single Pass feature on this phone, and not related to the carrier's network. This phone supports only Single Pass because it has adopted the single-chip design, which can significantly increase standby time and reduce power consumption. You are advised to consult your local carrier to enable services such as "Missed call reminder", "Incoming call reminder," and "Secretarial service" to receive reminders for missed calls.

Connect headphones

Plug the headphone plug into the headphone jack on the phone, ensuring that the headphone plug is fully inserted.

Charge the phone

Insert one end of the data cable into the USB port on the phone and the other end into the charger or a compatible device. The phone will start to charge. After charging is complete, disconnect the phone from the charger or the compatible device and remove the charger from the socket.

It is recommended to charge the device for at least 30 minutes before turning it on for the first time.


Note:

Please use the data cable and charger that came with the phone.

Antenna

This phone is equipped with a built-in antenna. Please do not touch the antenna when it is transmitting or receiving signals. Touching the antenna may affect the quality of communication, cause the phone to use more power than is needed or shorten the battery life. The antenna is located inside the dotted circle. Please do not cover this area when holding the phone, as shown in the picture below:

A. GPS antenna/Wi-Fi antenna; B/C/D. Communication antenna.



Note:

The pictures used in these instructions are for reference only and may differ from your phone. Please refer to your phone during use.

Status bar icons and notifications

Meaning of status icons

The status bar at the top of the screen provides some basic status information of the phone, including signal strength, time and battery power.

	Signal strength
	SIM card has no signal
	Flight mode enabled
	Connected to Wi-Fi
2G/G/E	2G network*
3G/H/H+	3G network*
4G	4G network*
5G	5G network*
	Connected to Bluetooth device
	Vibrate mode enabled
	Silent mode enabled
	Do Not Disturb mode enabled
	You have a new message
	Alarm on
	Battery power

	
	Charging
	Data Saver is on
	Hotspot is on
	Location is on
	VPN is connected

Note:

The network symbol is displayed to indicate current operators and network settings. The 5G icon is for illustrative purposes only and can only be shown on 5G network supported mobile phones.

View notifications

When you receive a new event notification, its content will be displayed on the status bar. You can swipe the status bar down and tap the notification to view details.

Introducing the home screen

When no app is open on your phone, your home screen will be displayed. This device can have multiple home screens. Swipe left or right to switch between these home screens. If you swipe up on the home screen interface, you can see all the apps on your phone.

Change home screen settings

By tapping and holding a blank area of the home screen, you can change the home screen settings and add widgets or wallpapers according to your own preferences.

Search through the home screen

Tap on the Google icon and enter what you want to search for.

Add apps to the home screen

In the app drawer, tap and drag an app to move it to wherever you want.

Control centre

Swipe down from the top of the screen to open Control centre, where you can tap an icon to quickly enable or disable the feature corresponding to that icon.

Desktop apps

iManager

iManager can effectively clear junk files from your phone, secure your phone, and provide various management tools to make your phone easier to use.

Phone management

Optimise: Check your phone's status, optimise your phone with one tap, and view recommended optimisations to improve your phone's performance.

Space clean-up: Scan and clean the cache with one tap. This feature also provides personalised recommendations of items to clean up based on your phone usage and has multiple special cleaning tools, making it easier to clean up the phone storage space.

Security scan: Detect system vulnerabilities, viruses, Trojan horses, malware, risky networks, and other security risks with one tap, so that you can deal with them promptly. iManager also performs app security scans in the background to protect your phone in real time.

Data monitor: View your overall and app-specific mobile data or Wi-Fi usage. Tap an app to allow or not allow it to use mobile data in the background.

Note:

The carrier may adopt a different data traffic calculation method from that used by your device.

Apps & notifications: Configure app notifications and permissions.

More settings: On the iManager home page, tap  to go to the **Settings** page, where you can adjust the detailed settings of iManager and view more information.

Utility tools

More utility tools (such as privacy and security tools) are available to provide you with a better user experience.

Camera

Use Camera to capture photos and videos of wonderful moments in your life anywhere and anytime.

Open Camera

To open Camera:

- Tap the Camera icon on the home screen.
- On the lock screen, tap and hold the camera icon, and then swipe up.

Take a photo

To take a photo:

- Open Camera and tap the shutter button.
- Open Camera, choose Photo mode, and press a volume button.

Take multiple photos in quick succession

Open Camera, choose Photo mode, and tap and hold the shutter button. The number of photos captured will be displayed on the screen. Release the shutter button to stop shooting.

Record a video

To record a video:

- Open Camera and tap the video button. Tap the video button again to stop recording and save the video.
- Open Camera, choose Video mode, and press a volume button. Press the volume button again to stop recording and save the video.

View a captured photo or video

Tap the image in the lower left corner to view the captured photo or video.

Switch between the front and rear cameras

To switch between the front and rear cameras, tap the switch icon next to the shutter button.

Change the camera mode

Open Camera, swipe left or right on the screen, or tap to choose the mode you want.

Accessibility features

Open Camera, and turn accessibility features on or off at the top of the screen.

Flash: Tap the flash icon to adjust the flash mode.

HDR: When taking photos in environments with a strong backlight or a large contrast between bright and dark areas, turn on HDR mode to improve shadows and highlight details.

Tap  >  to adjust the detailed settings of Camera.

Tap  >  /  to show or hide framing lines.

Tap  >  to choose a self-timer option (such as Off or 3s).

Tap  >  to choose your preferred frame size.

Note:

Some features may vary depending on the device model. Please refer to your phone.

Albums

View the photos and videos you have captured and various images stored on your storage device.

Slideshow

1. In **Photos**, open a photo or video, and tap  > **Slideshow**.
2. In **Albums**, open a photo or video in a folder, and tap  > **Slideshow**.

Share or delete photos or videos

1. In **Photos**, tap  or tap and hold a photo or video to enter edit mode, check one or more photos or videos, and tap .

2. In **Albums**, open a folder, tap  or tap and hold a photo or video to enter edit mode, check one or more photos or videos, and tap .

Recover or permanently delete a deleted photo or video

Open Albums, tap **Recently deleted**, and do the following:

1. Tap and hold to choose the photo or video, and then tap  to recover or permanently delete it.
2. Open the photo or video, and then choose to recover or permanently delete it.

Note:

To use this feature, you need to turn on **Recently deleted** on your phone. Deleted photos and videos will then be temporarily stored in **Recently deleted** and permanently deleted after a certain period of time.

Edit images

In **Photos** or **Albums**, open an image, and tap  to edit the image.

Calculator

Calculator can be used in multiple modes to perform basic and advanced calculations.

Open Calculator

To access Calculator:

- Swipe up on the home screen. You will see all the apps on your phone. Enter **Calculator** in the search box to quickly locate and open Calculator.
- Swipe down from the top of the screen to open Control centre, and tap  in Control centre to open Calculator.

Change the calculator

In the Calculator app, you can change the calculator as needed.

-  Your phone uses the basic calculator by default, which can be used to perform simple arithmetic calculations.
- Tap  to switch to the scientific calculator, which involves advanced operators and functions.
- Tap  to switch to the currency conversion calculator, which can be used to convert exchange rates.
- Tap  to view the calculation history of the basic or scientific calculator.

Note:

You must connect your phone to the internet to use the currency conversion calculator.

Recorder

Use the Recorder app to record voice memos in your work and life. It uses the built-in microphone on your phone to record. In the **Recorder** app, you can perform the following actions:

Tap  to start recording. Tap  to pause recording. Tap  to stop and save the recording.  marks a time point.

Play a recording

To play a recording:

1. Choose the recording file and tap  to play or pause it. Drag the slider on the progress bar to go forwards or backwards.
2. Open the recording file to play it. To pause playback, tap . To continue playback, tap .  marks the time point. To change the speed, tap . To turn Speaker mode on or off, tap /. Tap a mark during playback to quickly jump to the marked location in the recording.

Share and delete a recording

Tap and hold the recording file you want to share or delete, or tap  > **Select**, check the recording file, and then tap /.

Set a recording as a ringtone

Tap and hold the recording file you want to set as a ringtone, or tap  > **Select**, check the recording file, and then tap  > **Set as ringtone**.

Trim a recording

Open the recording file you want to edit, tap  > **Trim**, drag the timeline slider, and tap / to preview or continue the recording. Trim a part of the recording, tap  to save or delete the selected part, and then tap .

Clock

The Clock app has four features: Alarm, Clock, Timer, and Stopwatch.

Alarm


1. To add an alarm, tap . To edit an alarm, tap the alarm to enter the alarm settings page. Tap / to switch to the analogue clock or digital clock, set up a recurring alarm, set the alarm sound, and tap  to save the alarm.
2. To delete one or more alarms, open Clock, tap  > **Select**, check the alarms, and tap . You can also tap and hold to choose the alarms and then tap  to delete them.

Clock

1. Tap  to add the time in cities worldwide.
2. Convert time zones: If you have added two or more cities, tap  > **Time converter**, and select a city, date, and time.

Timer

You can use the timer to count down from a specified time. Set the duration of time and tap  to start a timer.

During the countdown, you can tap  to add and start more timers, tap  to delete the timer, tap  to extend the timer for 1 minute, tap  to pause the timer and tap  to continue the timer, or tap **Reset** to reset the timer.

Stopwatch

Tap  to start a stopwatch. Tap  to record a lap time. Tap  to pause the stopwatch. Tap  to reset the stopwatch. Tap  to share or copy the lap times.

Compass

You can check out directions, longitude, latitude and the horizontal line with the compass. Before using the function, please make sure your phone is horizontal and away from electromagnetic interference so as to ensure accuracy.

Note:

1. Please enable a network connection and the location service before checking your current location.
2. When subject to severe interference, the compass will switch to the calibration window and can be used again after calibration.
3. The digital compass can only be used to assist navigation. Please do not use it to determine an accurate location, proximity, distance or directions.

vivo.com

You can learn more about vivo and our products on the **Home/Products** page, and provide feedback as well as find solutions to frequently asked questions on the **Support** page.

Note:

You must connect your phone to the internet to use this feature.

Music

You do not need to add songs manually. Your phone will scan for songs on the storage device automatically when turned on and add them to **Music**.

Lists

Open Music from the home screen and tap **Lists**. Tap **New playlist** to create a playlist of your favourite songs.

1. Edit a custom playlist: Open the playlist, tap , mark one or more songs, and then tap **Add to playlist/Remove**.

2. Delete a custom playlist: Tap and hold the playlist, and tap  in the pop-up window. Deleting a custom playlist will not delete the songs in it.

Search

When there are many songs, you can tap  and enter the name of a song, an artist, or an album to quickly find what you want.

Settings

Go to the  page to configure the settings for Music.

Scan for songs: Tap **Scan** to scan for songs on your phone. You can filter folders or songs to not display them in the Songs list.

Sleep mode: Drag the slider in the middle to set the amount of time you want your music to play for, and turn on **Sleep mode**. When **Sleep mode** is turned on, your phone will automatically stop playing music after the set amount of time is up. You can choose either to only stop playing music or to stop playing music and turn off your phone after the set amount of time is up.

Sound effect settings: Tap **Sound effect settings** to set your preferred sound effects.

Weather

Add cities

Tap  to go to the **City management** page, and tap  in the upper right corner to add more cities.

Check the weather

On the Weather home page, swipe left or right on the weather curve to see the temperature changes and weather conditions for the next 22 hours. To view another city, swipe left or right on the screen.

Rearrange the order of cities

Tap  to go to the **City management** page, tap , tap and hold , and move the city up or down to reorder it.

Delete a city

On the **City management** page, tap and hold the city you want to delete, and tap **Delete**.

Weather settings

Tap  to set your preferred weather display.

Note:

You must connect your phone to the internet to use this feature.

EasyShare

Use EasyShare to send or receive files without data usage.

Data-free, superfast file transfer

You can simultaneously transfer files of various types at a high speed without using data. For example, if you use EasyShare on an Android-powered device (source phone) to send files:

Tap , select the files to transfer, and tap **Send**. On the phone to which the files are to be transferred (target phone), tap  to search for the source phone or scan the QR code on the source phone to connect the phones. Then tap OK on the source phone.

Phone Clone

Phone Clone is secure and efficient and requires no data usage to quickly import data, including contacts, messages, and photos, from your old phone to your new phone.

On your old phone, tap  > . On your new phone, tap  > , select the operating system on your old phone, and scan the QR code on the old phone or manually connect to the old phone's hotspot.

Data backup

Download and install EasyShare on your PC, connect your phone to the PC via a USB cable, and then back up or restore data. You can also tap **Wi-Fi connection** on your phone, scan the QR code on the PC, and then back up or restore data.

Share EasyShare

To share EasyShare:

1. Scan the QR code to go to the official website and download and install EasyShare.
2. Share via Bluetooth or Wi-Fi.
3. Share via WhatsApp or SMS.

Notes

Create notes as you like to jot down your ideas and inspirations.

Create a new note

1. To create a new note:

- Tap  on the  page.
- Open a folder on the  page, and then tap .

2. You can perform the following actions in a note:

- Tap  to set the text formatting such as the font size.
- Tap  to create a to-do list. After you create the list, tap  to mark a task as completed.
- Tap  to set a reminder for the note.
- Tap  to add a photo to the note.
- Tap  to turn on recording mode.

- Tap  to change the note's background or add a table to the note.
- Tap  to undo or redo edits.

3. Tap  to save the note.

Mark a note

Open the note you want to mark, and tap .

Pin or hide a note

Tap and hold the note in the Notes list, and then tap **Pin/Hide** in the pop-up window.

Share or save a note

Open the note you want to share or save, and tap .

Delete notes

To delete one or more notes:

1. Tap and hold the note you want to delete, and tap **Delete** in the pop-up window.
2. In the Notes list, tap , select one or more notes, and then tap .
3. Open the note you want to delete, and tap .

Google apps

Google provides entertainment, social networking and other apps. Some apps may require you to sign in to your Google account in order to use them. For further information, visit the Help page of the app.

Introducing some features

Chrome/Google: Google Chrome is a popular browser used to search and visit web pages.

Gmail: Gmail is an email client that uses Google Mail services to send and receive emails.

Maps: Google Maps helps find your location while also showing you what's around. You can also fill in your commute information so it can show you traffic information for your reference.

YT Music: YouTube Music has the coolest new music and videos for you to enjoy. Stream or save music to your device.

YouTube: YouTube has a variety of videos for you to enjoy. You can even upload your own.

Photos: Google Photos is the perfect place to edit and manage your photos and videos from all different sources.

Assistant: Google Assistant can help you send SMS messages, make phone calls and plan routes all by using your voice.

Duo: Google Duo helps keep you in touch with friends and family through videos calls.

Files: Files is a file manager used to help you manage, share and clean up your saved files and apps.

Google Pay: Google Pay puts together all payment methods supported by Google so you can enjoy a quick and secure payment experience after entering your bank information once.

Calendar: Calendar can remind you of upcoming events by sending a notification to your phone when the event approaches.

Play Store: After signing in, you can find the latest Android apps, games, films, music and other amazing content. You can search for and download any content according to your needs.

Phone: The Phone app is used to make calls.

Contacts: Contacts is where you can save and manage your contacts.

Messages: You can use Messages to send and receive SMS messages, photos, videos, audio or other files.

Note:

Apps may be unavailable or vary in functions depending on your region and service provider.

Settings

Network & internet

● Wi-Fi

Turn on or off Wi-Fi in **Wi-Fi**. When Wi-Fi is on, choose the Wi-Fi network that you want to connect to.  indicates an encrypted network, which requires a Wi-Fi password. When your phone is connected to a Wi-Fi network, the Wi-Fi signal strength will be displayed as  in the status bar. The more bars, the stronger the signal. If there is no available Wi-Fi network or if Wi-Fi is off, your phone will connect to the data network for internet access. Once your phone is connected to a Wi-Fi network, it will connect to the network automatically when in range.

To add a Wi-Fi network that is not on the list of available networks, tap  and enter the network SSID. To connect to a hidden network, you must know the network name, password, and security type.

● SIM card & mobile network

From here, you can view the current SIM card status and adjust the SIM card settings according to your usage.

Mobile data: Turn on this option to use apps such as Browser and Mail over the data network. Carrier charges may apply. For details, consult your carrier.

Preferred SIM card: If you are using two SIM cards, set the preferred SIM card for mobile data and calls. Your phone will automatically use the preferred SIM card.

SIM card info and settings: Choose a SIM card to view or set the SIM card information (such as the SIM card name), primary network type, and data usage of each app on the SIM card.

●Hotspot & tethering

Share your Wi-Fi, Bluetooth, or USB network hotspot with other devices to allow them to access the internet via your Wi-Fi or data network.

To turn on a hotspot:

- Swipe down from the top of the screen to open Control centre, and tap .
- Go to **Settings > Network & internet > Hotspot & tethering > Wi-Fi hotspot**, and turn on the switch.

Manually set the hotspot name, usage security, and single-use data limit as needed.

●Data Saver

Data Saver prevents some apps from using data in the background and thereby helps reduce data usage. In **Not restricted by data limit**, turn on or off the switch for each app based on your data-saving needs.

●Network management

This list includes all apps allowed to access the data network or Wi-Fi. You can enable or disable the internet permission for these apps as needed.

●Aeroplane mode

You must turn on Aeroplane mode on your phone while flying in an aeroplane.

To turn on Aeroplane mode:

- Swipe down from the top of the screen to open the Shortcut Centre, and tap .
- Go to **Settings > Network & internet**, and turn on **Aeroplane mode**.

●VPN

Your company's VPN allows you to securely communicate private information over a non-dedicated network. For example, you can use the VPN to access your business emails.

Tap **VPN > +**, enter the VPN information received from the administrator, configure the VPN file, and save the settings. You can then enter your username and password to use the VPN.

●Private DNS

A private DNS can protect your privacy and security while connecting to a target URL.

To turn on/off or change the private DNS settings, tap **Private DNS** and follow the on-screen instructions.

Bluetooth & devices

●Bluetooth

With Bluetooth, you can connect to other Bluetooth devices such as earphones, car kits, speakers, phones, keyboards, and mice. It also allows you to transfer files, including documents, contacts, images, music, and videos, between two mobile devices (such as phones and tablets).

●Smart Mirroring

1. **Local file mirroring:** Play videos, images, and music from your phone on a connected device.
2. **Phone screen mirroring:** Display content on your phone screen and on a connected device at the same time. You can tap the screen controls on your phone to proceed.

●OTG

On-The-Go (OTG) is a technology that allows storage devices to transfer data without requiring a host. For example, with a USB OTG cable, you can connect your digital camera to a printer and directly print photos from the camera. Use an OTG cable to connect a storage device to your phone and turn on **OTG**. You can then open File Manager to manage the images, videos, and music files on the storage device.

●Print

You can use some apps on your phone to print. Before printing, add a printer that can get data over the internet.

●Chromebook

Connect your phone to a Chromebook to unlock the Chromebook with your phone or send and receive messages on the Chromebook.

●Nearby Share

To use this feature, you need to turn on Bluetooth and enable location services and register or sign in to a Google account. Nearby Share allows you to share or receive content from nearby contacts.

●Android Auto

To use this feature, you need to register or sign in to a Google account and have downloaded and installed the **Android Auto** app. Android Auto allows you to use Google Assistant to control the map, media, and messages while driving.

Display and brightness

Adjust the system settings such as the screen brightness and auto-lock time.

Adjust the screen brightness

To adjust the screen brightness:

- Swipe down from the top of the screen to open Control centre, and drag the slider (●) to adjust the screen brightness manually or tap **A** to enable auto-brightness.
- Go to **Settings > Display & brightness**, and drag the slider to adjust the screen brightness manually or enable **Auto-brightness** to make your phone automatically adjust the screen brightness based on the ambient light conditions.
- **Eye Protection** automatically adjusts the screen colour temperature to make the screen light warmer and softer, which can help reduce eye strain. You can turn it on immediately or at a set time as needed.
- **Dark theme** uses a solid black background, which can help reduce screen glare and extend battery life. You can turn it on immediately or at a set time as needed.

Auto-lock screen settings

In **Screen timeout**, select a preferred duration. The screen will lock automatically after it has been idle for the selected duration.

Screen rotation settings

Auto-rotate screen allows the screen to rotate automatically when you rotate your phone between portrait and landscape modes.

Screen colour mode/colour temperature settings

In **Screen colours**, manually adjust the screen colour mode (or colour temperature) based on your usage habits.

Font settings

Font size: Different font sizes are available for you to choose as needed.

Font style: Check the current font or download and use other fonts.

Status bar settings

In **Status bar**, turn on or off display options related to the status bar (such as the network speed display or battery percentage).

Screen saver settings

In **Screen saver**, set a screen saver to show up when your phone is charging or docked.

Screen refresh rate

Screen refresh rate: A higher screen refresh rate results in smoother animations, higher system power consumption, and more heat generation. Refer to the feature description and select a screen refresh rate as needed.

App aspect ratio settings

Full screen display of apps: Apps that do not automatically display in full screen are listed here. To display an app in full screen mode, turn on the switch for the app.

Display at the top of the screen: Apps that display/do not display at the top of the screen are listed here. Tap an app to learn about the display features and select a display mode as needed.

Lock screen & wallpaper

Themes and wallpapers

Use your preferred themes or wallpapers. You can also use an image in Albums as a wallpaper.

Other settings

Lock screen settings: Use your preferred lock screen styles. You can also enable "**Change lock screen wallpaper based on theme**". Tap "**Add text on lock screen**" and enter any text or symbol to display on the lock screen.

Home settings: Here you can change settings related to your phones home screen layout, app icon badges, and more, such as app icon badge display forms, home screen style/layout, and whether to add new app icons to the home screen.

Simple Mode

Turn on Simple Mode to use the home screen with a simple layout and a larger font size.

Dynamic Effects

A variety of animation styles are provided under the corresponding feature. You can select and apply your favourite style.

Sound

Set your preferred sound profile in **Settings > Sound**.

Volume button adjustment

Use the volume buttons to adjust the media or ringtone volume as needed.

Phone vibration settings

In **Vibrate for incoming calls/Vibrate for notifications**, set the vibration mode or strength based on your usage habits.

Do Not Disturb

In **Do Not Disturb** mode, your phone will only receive notifications from important contacts and apps. You can specify which contacts or apps to allow notifications from as needed.

To turn on Do Not Disturb:

- Swipe down from the top of the screen to open Control centre, and tap .
- Go to **Settings > Sound > Do Not Disturb**, and tap **Turn on now**.

Custom ringtones

For example, to **set an alarm ringtone**, pick a ringtone from the provided options or use an audio file on your phone as a custom ringtone. You can set other message or notification ringtones in a similar manner.

Other sound and vibration settings

Sounds: Sounds can also be set for touches, charging, and other occasions. Turn on or off the sounds based on your usage habits.

Touch vibration: Adjust the touch vibration frequency or enable haptic feedback.

Apps

This list includes all apps and services installed on this device. You can set detailed permissions for apps and notifications based on your usage habits.

View or edit app information

All apps and recently used apps are listed here. Tap an app to view its build number, used storage space, and usage duration, and adjust its permission settings as needed.

Screen time

Tap ▼ to check how much time you spend on each app, how many notifications you have received, and how often you unlock/open an app on the current day.

Set app timers: Tap ⌚ to set a daily timer for an app. When the app timer ends, the app will be paused for the rest of the day.

Default apps

When you have multiple apps that can be used for the same task, you can choose the app to use by default.

Battery

Check the current battery usage, power consumption, and more, and switch to Battery Saver or Balanced mode as needed.

Manage the power consumption of background apps

In **Background power consumption management**, check the power consumption of each background app on the current day, and allow or don't allow certain apps to continue running in the background as needed.

Note:

The power consumption is approximate and may vary depending on usage.

RAM and storage space

Go to the **RAM and storage space** interface to view the memory usage of the storage devices, as well as format the storage devices. Formatting will remove all data from the phone storage. Please make sure that you have backed up important data before formatting.

Security

Update your security status or configure security features to keep your phone secure.

Security status

Check your app security scan/update status. **Find My Device** can help you remotely locate your device and keep your phone data secure when your device is lost.

Device security

Set a screen lock or enrol your fingerprint (or face) to improve your phone's security.

1. **Lock screen password:** Tap **Screen lock** and set a lock screen password (such as a pattern or a numeric password) as needed.
2. **Fingerprint unlock:** Set a secondary screen unlock method.. After setting a lock screen password and enrolling your fingerprint, turn on **Unlock**. You can then use the enrolled fingerprint, draw the unlock pattern, or enter your numeric password to unlock the phone.
3. **Face unlock:** Set a secondary screen unlock method.. After setting a lock screen password and enrolling your facial data, turn on **Unlock**. You can then unlock the phone with your face when the screen is on and locked.
4. **Smart Lock:** After setting a lock screen password, use Smart Lock to keep your phone unlocked in certain circumstances (for example, when your phone is on you or in certain locations). Each option is described in detail.
5. **Privacy & app encryption:** A privacy password is used to encrypt apps, messages, and notes. Follow the on-screen instructions to set your privacy password and security questions.
 - Use the privacy password to encrypt apps: Turn on the switch for the apps you want to encrypt, then lock the screen or exit the apps. You can also specify from when the app lock takes effect as needed.
 - Use the privacy password to hide apps: Turn on the switch for the apps you want to hide. The apps will then be completely closed, which means they will no longer be displayed on the home screen or in the list of recent apps or other app lists, nor will they receive new messages. You can also specify how and from when the apps are hidden (for example, when you lock the screen or exit the apps) as needed.

Privacy

Here is a collection of functional settings for the security of the phone, such as system security and privacy. Adjust the settings as needed.

Description of some features

Permission manager: Check the apps that are currently allowed/denied access to permissions such as Storage, Location, an Calendar, and adjust the app permissions as needed.

Show password: When enabled, the characters of a password will be displayed briefly during input.

Notifications on lock screen: Configure how notifications are displayed on the lock screen.

Recent apps preview: After "Blur recent apps" is on, you can turn on or off blur preview for specified apps as needed.

Screen capture protection: When enabled, third-party apps will be prohibited from taking screenshots or recording the screen during password input so as to prevent password disclosure.

Unlock to turn off: When this feature is enabled, you must unlock a locked device before to turning off or restarting it.

Note:

This feature will only appear when a lock screen password is set for your phone.

Location

You can enable the location function under **Settings > Location**. After enabling the function, apps such as Maps and Camera as well as third-party location-based apps can collect and use location

data. When you do not need location data, you can disable the function to save battery power.

Note:

It is recommended to use a Wi-Fi network where possible as the location service consumes a large amount of network traffic.

Ultra Game Mode

Your phone will automatically add downloaded games to Ultra Game Mode. You can also manually add games to Ultra Game Mode to let the games use Ultra Game Mode features. Tap the Add button and select games.

Choose a game mode

Esports Mode: Each feature is described in detail. Go to **Supported games** to check which installed games support Esports Mode, which provides pro players with a more immersive and smoother gaming experience. To turn on Esports Mode, bring up the sidebar in a supported game.

Off-screen Autoplay: To turn on this mode, bring up the sidebar in a game added to Ultra Game Mode. In Off-screen Autoplay mode, games will continue running when the screen is off or locked. This helps reduce power consumption while running games in the background.

Experience enhancement/Do Not Disturb settings

Features such as sound effects and visual effects are available to enhance your gaming experience. Go to the features and follow the on-screen instructions to learn more about and enable the features as needed.

Shortcuts and Accessibility

●S-capture

Use S-capture to take screenshots, record the screen, or record animated GIFs.

To take a screenshot:

- Swipe down from the top of the screen to open Control centre, tap , and select an appropriate screenshot method.
- Swipe down with three fingers to take a quick screenshot.
- Press and hold the Power button and Volume down button simultaneously to take a quick screenshot.

Turn on **Screenshot floating window**. A floating window will be displayed when you capture a screenshot. You can tap the floating window to preview, edit, and share the screenshot.

●Smart Split

Smart Split allows you to handle two apps easily at the same time. In some apps, an incoming message will be displayed as a floating icon. Tapping the icon will split the screen into two halves, giving space to both apps.

Screen-split: For details on how to enable screen-split in different circumstances, refer to the on-screen text and animated instructions.

Recommended screen-split apps: When enabled, the system can intelligently predict which app you want to open on a split screen and recommend it to you as the first choice.

●Smart Motion

Here is a collection of various Smart Motion features. Go to the features and follow the on-screen text or animated instructions to learn about and enable the features as needed.

●Quick action

Turn on **Quick action** and select a feature or app (such as Torch or Camera). You can then press and hold the Volume down button to quickly start the selected feature or app when the screen is off.

Note:

Quick action cannot be used during music playback or if the IR sensor is blocked.

●Easy Touch

Easy Touch provides easy access to some commonly used apps or shortcuts on your phone. When enabled, Easy Touch will be displayed on the screen as a floating button (like .

Description of some features:

- Customise features: Go to **Customise menu** and tap  to add other shortcuts or commonly used apps to Easy Touch.
- Change skins: Easy Touch is available in multiple skins. Go to **Personalised skins** and choose your preferred skin.
- Set display effects: In **Display effects**, set the idle visibility of Easy Touch, specify whether Easy Touch automatically moves to a screen edge after 3 seconds of inactivity, and choose whether to automatically hide Easy Touch in full screen mode.

●Task timer

After you set **Scheduled power on/off**, your phone will turn on or off automatically as scheduled. Before turning off, the phone will ask you to confirm whether you want to turn it off. If not, tap **Cancel**. If you do not confirm or cancel the power off, your phone will turn off after 60 seconds.

You can set **Scheduled vibration mode/Scheduled aeroplane mode** in a similar manner.

●One-handed

When **Access mini screen using gesture** is enabled, you can swipe in from the edge of the screen and then swipe out to open a mini floating window.

Tap and hold the title bar of the mini floating window to drag it to your preferred position on the screen. Tap  and zoom with two fingers or drag the edit icon to adjust the mini screen size.

●Accessibility

Accessibility features let you better interact with your phone apps. They make apps more functional and your phone easier to use. Turn on/off and set accessibility features to suit your needs.

Description of some features:

- **Downloaded apps:** View downloaded features that can read the content of the screen or use buttons to control the phone. For details on how to use a feature, refer to the relevant text description.
- **TalkBack:** Enable this feature to hear the on-screen text. You can select your desired engine, language, speed, and tone.
- **Display:** Configure display settings (such as the font size and zoom). For details on how to use a feature, refer to the relevant text description.
- **Interaction controls:** Configure options related to interaction with the phone (such as the response

time to screen taps or presses).

· **Audio & on-screen text:** Set your preferred sound channel and subtitles for playing audio.

Digital Wellbeing & parental controls

You can check the usage of the device here and adjust the settings of some functions to reduce the interference the device causes to you. You can also set up Parental Control to control and manage the use of the phone by your child.

Google

You can adjust some of the functional configurations provided by Google here. Tap  on the home screen to learn about detailed solutions to related problems.

Accounts

Add account

To add an account, tap **Add account** and select the account type. You can add multiple types of accounts.

You must register and sign in to a dedicated Google account to use some features on the phone.

Auto-sync app data

Turn on **Auto-sync app data** to automatically sync app data.

Note:

You must connect your phone to the internet to use this feature. The auto-sync feature uses power and data. You are recommended to turn it off once you have finished syncing.

System

● System navigation

Gesture navigation: Use gestures to quickly go back to the previous screen, go to the home screen, and switch between apps.

3-button navigation: Tap buttons to quickly go back to the previous screen, go to the home screen, and switch between apps. You can change the order and styles of the buttons as you like.

● Languages & input

To add a language, tap **Languages** > . To set an added language as the default, drag the language to the top of the list.

To manage supported input methods, tap **Onscreen keyboard** >  and turn on or off input methods as needed.

●Date & time

The phone can get the correct time over the internet. You can manually adjust the time zone and time and turn on or off the 24-hour format as needed.

●Back up or restore data

You can back up apps and data on your phone on the Google server (or vivo Cloud), and restore backed up information to your phone.

●Reset options

Reset your phone's network/Bluetooth settings and restore or erase all data as needed.

Note:

Using **Erase all data** will delete all data from your phone's internal storage.

●Phone Clone

Phone Clone clones data from an old phone to a new phone with one tap without using data.

For example, on your new vivo phone, tap  and select the type of your old phone (iPhone or Android phone). Then open the app on the old phone and scan the QR code as prompted.

About phone

Go to **About phone** to find a variety of information related to the phone. For legal information, go to **About phone** > **Legal information**.

Customer service: You can find the phone manual, E-warranty card and other information here to make better use of your phone.

Note:

Before using this function, please enable network access on your phone.

Developer options

Developer options is used by Android developers. Enabling set options under **Developer options** may lead to crashes or exceptions occurring to your apps or device. Please use it with caution.

Before using a PC tool to manage the device, please enable **USB debugging**. The **USB debugging** switch is under the **Developer options** menu. Steps to access the **Developer options** menu:

1. Enter **Settings** > **About phone**>**Software information**.
2. Tap seven times on **Build number**.
3. The **Developer options** menu will appear in **Settings** >**System**.

System update

You can use **System update** to easily and quickly upgrade your phone system. First, enable Wi-Fi or data network. Then go to **Settings** and tap **System update**. The phone will automatically detect new software versions, which you can simply download and install.

Note:

A recovery or system update that is not performed by the Company may cause security risks. It is recommended that you back up important data to a storage device before upgrading. System update may incur a high amount of data traffic. You are advised to use Wi-Fi.

App Clone

Go to **App Clone**, and turn on the switch of installed apps that support such function. When the switch is on, a clone app will be generated on the screen.

Name the cloned app "Π·xxx" to distinguish it from the original app. This function allows you to sign in with another account so there is no need to switch between accounts in one app.

Note:

1. Uninstalling or closing the original app will also delete the cloned app and its data.
2. Dual apps may increase data usage. Please clean up data with iManager.
3. In view of actual usage scenarios and third-party app restrictions, this feature only supports apps with sign-in accounts. Other apps do not currently support this function.
4. App clone can only be used on vivo's original home screen and may not work well on other types of home screens.

Multiple users

Description of user types

User: A person who doesn't own but may often use your device. Each user has their own exclusive space and can set their own home screen, sign in to accounts, and install apps.

Guest: A person who uses your device for a short time. Guests also have their own space on the phone, which can be easily deleted by you when no longer used.

Add or remove a new user

To add a new user, turn on **Multiple users** and tap . You can then switch to the user account and let the user set up their exclusive space on the phone.

Remove a user:

- If you are the owner of the phone, tap the username and then tap . All apps and data under this username will be deleted.
- If you are not the owner of the phone, tap  and then tap "Delete XXX (username)" in the pop-up window. User deletion cannot be undone. The phone will then switch back to the owner's space.

Notifications

Chat settings

Specify a way to receive SMS messages or message notifications from apps. Prioritised or edited chats are displayed here.

To edit a chat, swipe down from the top of the screen to open Shortcut centre, and tap and hold the chat you want to edit.

Management

Here you can view the notification history from certain apps or the entire phone, and you can also set whether to allow apps and devices to read notifications.

1. To edit a single notification, swipe down from the top of the screen to open Shortcut centre, tap and hold the notification, and tap  to turn on or off the app notification and change the notification type as needed.
2. To clear a notification, swipe left or right on the notification or tap "Clear all" under all notifications.

Note:

Some notifications can only be cleared after relevant actions have been performed.

Regular

Here is a collection of notification-related settings, such as notification sound, notification delay, and display forms of home screen app icon badges. You can turn on/off or select corresponding options according to your preferences.

Wireless Emergency Alerts

After you turn on Wireless Emergency Alerts, you can manage the emergency alerts (such as threat alerts or AMBER alerts) you want to receive, set the alert frequency, and turn on or off vibration.

Device Maintenance

About maintenance

A thorough understanding of the maintenance and servicing of the phone may help you use your phone more safely and effectively, extending its service life as far as possible. For more information, refer to the paper manual included with your device.

Phone and accessories

This phone uses the Android operating system. To view the phone's version, go to **Settings > About phone**.

In **Settings > About phone > Legal information > Safety information**, you can learn the safety considerations for this device to help you use it in a safer way.

Help

If you have any questions while using your phone, contact your network carrier or our after-sales service centre. Go to **Settings > About phone > Customer service > Service centre** to find our after-sales service hotline.

Supported file formats

Video recordings	mp4
Pictures	png, jpg, bmp, gif
Sound recordings	m4a
Music	mp3, ogg, wav, midi, flac, m4a, aac, amr, awb, mp2
Video	avi, mp4, 3gp

Instructions for connecting to USB

Connect your phone to a PC using a USB cable, swipe down the notification bar on your phone, tap the charging connection notification, select **File transfer** on the redirected page, so that you can manage files on your phone using the PC.

Windows

1. Users of Windows 7 and above do not need to install any drivers. Double-click "Computer" (Win 7) or "This Computer" (Win 10) on the desktop to view your device, and then double-click it to copy and manage the files on your phone.
2. Windows XP users need to upgrade to Windows 7 or later or download and install the MTP plug-in to manage phone files from their computer.

Note:

To use the function properly, computers running Windows XP need to install Windows Media Player 11 or above.

Mac

1. Mac OS users need to download "AndroidFileTransfer.dmg" to manage files on the phone.
2. MacOS users need to download and install the MTP plug-in to manage phone files from their computer.

Linux

Manage files on the phone using mtpfs software:

1. Install the tool "sudo apt-get install mtp-tools mtpfs";
2. Create a new directory "sudo mkdir /media/mtp";
3. Modify the directory permission "sudo chmod 755 /media/mtp";
4. Install the device "sudo mtpfs -o allow_other /media/mtp", then you can manage files on the phone using File Manager;
5. Uninstall the device "sudo umount/media/mtp".

During installation, do not disconnect the USB data cable connecting the phone and the computer. If the mtpfs software cannot be used after being installed, please restart the computer or follow steps 1-5 to reinstall the software.